



#### SPECIFICATIONS

- Model No.: Sub-Sabre E1
- Burn Time: 4 hours (high) 8 hours (low)
- Brightness: approximately 150 lumens
- Battery: AAA\*3 (not included)
- Waterproof: 50 metres
- 3 Modes: High / Low / Flash

Before you use this Sub-Sabre E1, it is important to read this manual. Please follow the correct procedures for pre-dive inspection, and post-dive maintenance.

#### Pre-Dive Care:

1. Make sure the batteries are not expired and have full power.
2. Check the O-rings are in good condition and lubricated with silicone grease.
3. Ensure the strobe light is in good condition and free from faults, the housing is securely tightened.
4. Always check the light operates correctly by turning on.
5. Do not mix different brands, different types, or new & old battery cells as this may cause battery deterioration.
6. Only use top quality batteries.

#### Post-Dive Maintenance:

1. Rinse the light thoroughly with fresh water and dry it with a towel.
2. Inspect the O-Rings, ensuring they are clean, dry and free from dust or dirt to prevent flooding.
3. Make sure the O-Rings are in good condition and then lubricate with silicone grease.
4. Disconnect and remove batteries for storage.
5. Store the light in a cool and dry place away from direct sunlight. Never store at a temperature above 40°C or below -20°C.
6. Do not allow your light to be dragged on floor or dropped on the ground.
7. Avoid contact with sharp objects and ensure that heavy items are not placed on top.

It is user's responsibility if any damage caused by improper operation or without following the manual steps as indicated.